

tobramycin surface ih sample method

storage conditions	At least 21 days at ambient temperature, 2 – 8 ° or ~ -20 °
shipping requirements	Ambient temperature, overnight
swabbing media	Four CleanTips swabs TX740B; in glass test tube with screw cap
swabbing solution	DI water

If you wish to submit a sample, please follow the sample submission procedures found at safebridge.com/laboratory/sample-submission. SafeBridge regularly develops new and custom industrial hygiene air and surface sampling methods. For more information, please call (650) 961-4820. SafeBridge Consultants, Inc. is the premier occupational health and safety and risk assessment consulting firm to the pharmaceutical, biotechnology, and fine chemical industry. Learn more at safebridge.com.