

armour thyroid power t4 air ih sample method

shipping requirements	Ambient temperature, overnight
sampling media	25 mm Teflon filter, 1 micron pore size; support pad; in 2-piece polypropylene cassette
sampling rate	3 L/min
recommended minimum sampling volume	210 L

If you wish to submit a sample, please follow the sample submission procedures found at safebridge.com/laboratory/sample-submission. SafeBridge regularly develops new and custom industrial hygiene air and surface sampling methods. For more information, please call (650) 961-4820. SafeBridge Consultants, Inc. is the premier occupational health and safety and risk assessment consulting firm to the pharmaceutical, biotechnology, and fine chemical industry. Learn more at safebridge.com.