

naproxen sodium air ih sample method

shipping requirements	Ambient temperature
sampling media	A) 37 mm glass filter 1 micron pore size, support pad in 2-pc polystyrene cassette (closed face monitoring)B) 37 mm glass filter 1 micron pore size, support pad in 3-pc polystyrene cassette (open face monitoring)C) 25 mm glass filter, 1 micron pore size in IOM cassette
sampling rate	A) 3 L/min, 10 L/min B) 20 L/min C) 2 L/min
recommended minimum sampling volume	45 L

If you wish to submit a sample, please follow the sample submission procedures found at safebridge.com/laboratory/sample-submission. SafeBridge regularly develops new and custom industrial hygiene air and surface sampling methods. For more information, please call (650) 961-4820. SafeBridge Consultants, Inc. is the premier occupational health and safety and risk assessment consulting firm to the pharmaceutical, biotechnology, and fine chemical industry. Learn more at safebridge.com.